



**MacDermid  
Design Ltd**

A FULL SERVICE METAL FABRICATION COMPANY

 [www.macdesignltd.com](http://www.macdesignltd.com)

2650 E. Mohawk Lane, Suite 152, Phoenix, Arizona 85050  
Phone: 602-482-7215 Email: [info@macdesignltd.com](mailto:info@macdesignltd.com)

### VEHICLE APPLICATION

- |   |   |
|---|---|
| <ul style="list-style-type: none"><li>• 2022-2025</li></ul> | <ul style="list-style-type: none"><li>• RZR Pro R</li><li>• RZR Pro R 4</li></ul> |
|---|---|

### HARDWARE INCLUDED

(2) Weather Strips

### TOOL LIST

- |   |  |
|---|--|
| <ul style="list-style-type: none"><li>• Body Clip Removal Tool/Flathead Screwdriver</li></ul> |  |
|---|--|

### INSTALLATION NOTES

\*\*\*READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE BEGINNING INSTALLATION. FAILURE TO DO SO MAY RESULT IN DAMAGE TO PRODUCT\*\*\*

\*\*\*LID OF STORAGE BOX IS SPRING LOADED FOR AN ADDITIONAL 75LBS. DO NOT OPEN LID UNLOADED WITHOUT APPLYING DOWNWARD FORCE TO TOP TO PREVENT INJURY\*\*\*

\*\*\* MACDERMID DESIGN IS NOT RESPONSIBLE FOR ANY DAMAGE OR FAILURE RESULTING FROM IMPROPER INSTALLATION\*\*\*

## DISCLAIMER

This product is warranted against manufacturer defects only. Any claim against a defect must be made within 7 days of receipt. Please visit our website [www.macdesignltd.com/return-policy](http://www.macdesignltd.com/return-policy) for more information.

## INSTALLATION

1. For better access to the area, clean the rear bed tray area before install, do this before installing the Pro R 35 storage box.
2. Remove the inside vent covers with a body tool or flathead by prying upward on the center pin of the body clips holding them to the side intake vents. Place to the side for reuse later. (Figure 1)



**FIGURE 1**



3. Next grab the Macdermid Design Vent covers and place them over the vent. (Figure 2)



**FIGURE 2**

4. Grab the center pin of the body clips you placed aside and then put them in the two holes on the top of the vent covers. Press down on the top to pop them into place.(Figure 3)



**FIGURE 3**

5. Now you can start installing your storage box!

